

Mounting kit watchstrap transponder comfort

Fast & easy exchange and replacement of bracelets by yourself

Product information



Mounting kit scope of supply::

- 1 x Premium spring bar cutlery
- 10 x Stainless steel spring bar
- 25 x Bracelet comfort consisting of two parts including pre-assembled stainless steel spring bar



Replacement bracelets scope of supply:

- 10 x Stainless steel spring bar
- 25 x Bracelet comfort consisting of two parts including pre-assembled stainless steel spring bar

Mounting instructions:



Disassembly

1. Grab the thin, movable part of the spring bar with the fork by putting the tool in the gap between bracelet and bracelet holder.
2. Press the spring bar together until the holding pin pops out.
3. Remove spring bar on the opposite side.
4. After removing the second spring bar in the same way, the bracelet can be changed. When inserting the new bracelet, please note that the part with the buckle belongs to the upper end.

Mounting

1. Put the spring bar through the bracelet and insert the holding pin to the end of the bracelet holder.
2. Push the opposite holding pin into the spring bar with the fork of the spring bar cutlery and lead it in such a manner that it can finally be inserted neatly into the bracelet holder.
3. After setting down the spring bar cutlery, please push the holding pin through the spring in the spring bar entirely into the bracelet holder. The spring bar is now firmly fixed.

Colors – bracelet:

RAL 1016 Sulphur yellow	Pantone 802C Neon green
RAL 2008 Light red orange	RAL 6024 Traffic green
RAL 3000 Flame red	Pantone 801C Neon blue
Pantone Rhodamine Red C Pink	RAL 5017 Traffic blue
Pantone Medium Purple C Violet	RAL 9017 Traffic black

*All Pantone and RAL indications are guide values. Slight deviations of the end product reserved!

Variations:

- Optionally in the lengths 250mm / 220mm
- Optionally in the colors indicated (Only one combination of color and length per set possible!)